






HONDA




Engine	D14Z1/D14Z2
OEM	
Mould number	CS-01676-RU001
ERP	VC.0379
AJUSA	14070800



Engine	F20A F20A3 F20A5 F22A1 F22A4 F22B1
OEM	12341-PT0-000
Mould number	HO-02-01
ERP	VC.0030




Engine	F22B1/F22BS
OEM	06110-P0A-A02
Mould number	HO-17-01
ERP	VC.0177
AJUSA	52128500




Engine	D17A
OEM	12341-P2A-000
Mould number	HO-18-01
ERP	VC.0108
AJUSA	




Engine	D15Z1 D16Z6 D16ZD D15B2 7
OEM	12341-P08-000
Mould number	HOB-01-01
ERP	VC.0179
AJUSA	



Engine	CM4/CM5
OEM	12341-PAN-000
Mould number	HOC-01-01
ERP	VC.0188
AJUSA	



Engine	GD8/GD3/B5B18/L15A1
OEM	12341-PWC-000
Mould number	HOD-01-01
ERP	VC.0133
AJUSA	




Engine	L13A3 L12A2
OEM	12341-PWA-000
Mould number	HOD-15-01
ERP	VC.0020
AJUSA	56033300




Engine	D15B
OEM	12341-PM6-000
Mould number	HOE-01-01
ERP	VC.0123
AJUSA	



Engine	B20B
OEM	12341-PR4-A00
Mould number	HOG-01-01
ERP	VC.0147
AJUSA	



Engine	D14Z6/D17A/D16W8/D16V1/D15Y3
OEM	12341-PLC-000
Mould number	HOH-01-01
ERP	VC.0128
AJUSA	




Engine	A20A
OEM	12341-PH4-000
Mould number	HOI-01-01
ERP	VC.0097
AJUSA	



Engine	EW
OEM	
Mould number	HOJ-01-01
ERP	VC.0071
AJUSA	





TOYOTA




	Engine 1AZFE/2AZFE	OEM 11213-28021	Mould number 1AZFE-01-01	ERP VC.0183
	Engine 1DZ	OEM	Mould number 1DZ-01-01	ERP VC.0468
	Engine 1GEU/1GE	OEM 11213-70010	Mould number 1GEV-01-01	ERP VC.0002
	Engine 1GGE	OEM 11213-88302	Mould number 1G-GE-01-02	ERP VC.0228
	Engine 1GRFE	OEM	Mould number 1GRFE-01-01	ERP VC.0483
	Engine 1GRFE	OEM	Mould number 1GRFE-02-01	ERP VC.0484
	Engine 1HZ/1DZ	OEM 11213-17010	Mould number 1HZ-01-01	ERP VC.0247
	Engine 1KD	OEM	Mould number 1KD-01-01A	ERP VC.0489
	Engine 1KR-FE	OEM 11213-40030	Mould number 1KRF-01-01	ERP VC.0074
	Engine 1KZ-TE	OEM 11213-67010	Mould number 1KZ-01-01	ERP VC.0140
	Engine 1MFE	OEM 11213-20020	Mould number 1MFE-01-01	ERP VC.0180
	Engine 1MFE	OEM 11213-20010	Mould number 1MFE-02-01	ERP VC.0138
	Engine 1N	OEM 11213-55011	Mould number 1N-01-01	ERP VC.0114
	Engine 1ND	OEM	Mould number 1ND-01-01	ERP VC.0460
	Engine 1NZFE/2NZFE	OEM 11213-21011	Mould number 1NZFE-01-01	ERP VC.0166
	Engine 1RZ	OEM	Mould number 1RZ-01-01	ERP VC.0225
	Engine 1SLU/2SLU	OEM 11213-63010	Mould number 1SLU-01-01	ERP VC.0112
	Engine 1TR	OEM 11213-75040	Mould number 1TR-01-01	ERP VC.0221
	Engine 1VZFE/VZV20	OEM 11213-62010	Mould number 1VZFE-01-02	ERP VC.0115
	Engine 1ZZFE/3ZZFE/4ZZFE	OEM 11213-22050	Mould number 1ZZFE-01-01	ERP VC.0189
	Engine 2C/2CT/CR21/CT141	OEM 11213-64020	Mould number 2C-01-01	ERP VC.0031
	Engine 2C-E	OEM	Mould number 2C-E-01-01	ERP VC.0403
	Engine 2E	OEM 11213-10010	Mould number 2E-01-01	ERP VC.0091
	Engine 2JZGE	OEM 11213-46010	Mould number 2JZGE-01A-01	ERP VC.0232
	Engine 2JZGE	OEM 11213-46020	Mould number 2JZGE-01B-01	ERP VC.0231
	Engine 2JZGE	OEM 11213-46030	Mould number 2JZGE-20-01	ERP VC.0446
	Engine 2MZFE	OEM 11213-20030	Mould number 2MZFE-01-01	ERP VC.0397
	Engine 2MZFE	OEM 11214-20030	Mould number 2MZFE-02-01	ERP VC.0398
	Engine 2NRFE	OEM	Mould number 2NRFE-01-01	ERP VC.0458
	Engine TCR10 20/2TZFE	OEM 11213-76020	Mould number 2TZFE-01-01	ERP VC.0220
	Engine TCR10 20/2TZFE	OEM 11214-76010	Mould number 2TZFE-02-01	ERP VC.0090
	Engine 2ZR	OEM	Mould number 2ZR-01-01	ERP VC.0208
	Engine 3ALU 4ALU 4A 4AL 2A	OEM 11213-15040	Mould number 3ALU-01-01	ERP VC.0163
	Engine 3B/BU3/BB20/BJ60	OEM 11213-56011	Mould number 3B-01-01	ERP VC.0214
	Engine 3F	OEM 11213-61020	Mould number 3F-01-01	ERP VC.0242
	Engine 3GRFE	OEM 11213-31040	Mould number 3GRFE-01-01	ERP VC.0204
	Engine 3GRFE	OEM 11214-31020	Mould number 3GRFE-02-01	ERP VC.0152
	Engine 3RZ/3RZFE	OEM 11213-75030	Mould number 3RZ-01-01	ERP VC.0223
	Engine 3VZFE/4VZFE/5VZFE	OEM 11213-62020	Mould number 3VZFE-01-02	ERP VC.0125
	Engine 5AFE/5AF/5AE91	OEM 11213-15070	Mould number 5AFE-01-01	ERP VC.0116
	Engine 4EFE/5EFE	OEM 11213-11041	Mould number 5EFE-01-01	ERP VC.0083
	Engine 4EFE/5EFE	OEM 11213-22050	Mould number 5EFE-02-01	ERP VC.0020
	Engine 5M/ME/4M/MP/MPU	OEM 11213-41020	Mould number 5M-01-01	ERP VC.0240
	Engine 5S-01-01	OEM 11213-35010	Mould number 5S-01-01	ERP VC.0317
	Engine 3SFE/4SFE/5SFE	OEM 11213-74020	Mould number 5S-01-02	ERP VC.0024
	Engine 3SFE/4SFE/5SFE	OEM 11213-74020	Mould number 5S-01-01	ERP VC.0317
	Engine 7AFE	OEM 11213-16040	Mould number 7AFE-01-01	ERP VC.0418
	Engine 14B/11B	OEM 11213-58030	Mould number 14B-01-01	ERP VC.0210
	Engine 21R/22R	OEM 11213-35010	Mould number 22R-01-01	ERP VC.0034
	Engine L400/1UZ	OEM 11213-75040	Mould number L400-01-02	ERP VC.0155
	Engine 2ZL	OEM 11213-11043	Mould number VIVA-01-01	ERP VC.0043
	Engine 2L L	OEM 11213-54030	Mould number 2L-01-01	ERP VC.0036
	Engine 3VZ	OEM 11213-97403	Mould number 3VZ-01-02	ERP VC.0063
	Engine 1FZFE/2JZGE	OEM 11213-66020	Mould number FZ80-01-01	ERP VC.0235
	Engine 1ARFE	OEM 11213-42010	Mould number 1ARFE-01-01	ERP VC.0334
	Engine 1TR	OEM 11213-75040	Mould number 1TR-01-01	ERP VC.0492
	Engine RB20E/RB24S	OEM 13270-57S00	Mould number RB24-01-01	ERP VC.0327
	Engine 2LT/3L/5L	OEM 11213-54050	Mould number 2L/3L-04-01	ERP VC.0026
	Engine 2Y/3Y/4Y/4V/491Q	OEM 11213-7020	Mould number 4V/3Y-04-01	ERP VC.0150
	Engine 7MGE/7M	OEM 11213-42020	Mould number 7M-01-02	ERP VC.0229
	Engine 4AF/5AF/AE91	OEM 11213-15050	Mould number 5AF-01-01	ERP VC.0118
	Engine 4EFE/5EFE	OEM 11213-11041	Mould number 5EFE-01-01	ERP VC.0083
	Engine 3GRFE	OEM 11213-31040	Mould number 3GRFE-01-01	ERP VC.0204
	Engine 3GRFE	OEM 11214-31020	Mould number 3GRFE-02-01	ERP VC.0152
	Engine 3RZ/3RZFE	OEM 11213-75030	Mould number 3RZ-01-01	ERP VC.0223
	Engine 3VZFE/4VZFE/5VZFE	OEM 11213-62020	Mould number 3VZFE-01-02	ERP VC.0125
	Engine 5AFE/5AF/5AE91	OEM 11213-15070	Mould number 5AFE-01-01	ERP VC.0116
	Engine 4EFE/5EFE	OEM 11213-11041	Mould number 5EFE-01-01	ERP VC.0083
	Engine 3GRFE	OEM 11213-31040	Mould number 3GRFE-01-01	ERP VC.0204
	Engine 3GRFE	OEM 11214-31020	Mould number 3GRFE-02-01	ERP VC.0152
	Engine 3RZ/3RZFE	OEM 11213-75030	Mould number 3RZ-01-01	ERP VC.0223
	Engine 3VZFE/4VZFE/5VZFE	OEM 11213-62020	Mould number 3VZFE-01-02	ERP VC.0125
	Engine 5AFE/5AF/5AE91	OEM 11213-15070	Mould number 5AFE-01-01	ERP VC.0116
	Engine 4EFE/5EFE	OEM 11213-11041	Mould number 5EFE-01-01	ERP VC.0083
	Engine 3GRFE	OEM 11213-31040	Mould number 3GRFE-01-01	ERP VC.0204
	Engine 3GRFE	OEM 11214-31020	Mould number 3GRFE-02-01	ERP VC.0152
	Engine 3RZ/3RZFE	OEM 11213-75030	Mould number 3RZ-01-01	ERP VC.0223
	Engine 3VZFE/4VZFE/5VZFE	OEM 11213-62020	Mould number 3VZFE-01-02	ERP VC.0125
	Engine 5AFE/5AF/5AE91	OEM 11213-15070	Mould number 5AFE-01-01	ERP VC.0116
	Engine 4EFE/5EFE	OEM 11213-11041	Mould number 5EFE-01-01	ERP VC.0083
	Engine 3GRFE	OEM 11213-31040	Mould number 3GRFE-01-01	ERP VC.0204
	Engine 3GRFE			




NISSAN




Engine	B13/GA16DS/GA16DE
OEM	13270-73c10
Mould number	B13-01-01
ERP	VC.0174




Engine	CA20
OEM	
Mould number	CA20A-01-01
ERP	VC.0165




Engine	CA18S/CA20S/CA18N/CA20E
OEM	13270-01E00
Mould number	CA20S-01-01
ERP	VC.0010




Engine	CD17
OEM	13270-16A01
Mould number	CD17-01-01
ERP	VC.0134




Engine	E13
OEM	
Mould number	E13-01-01
ERP	VC.0065




Engine	E10S/E13S/E15S/E16S
OEM	13270-50A00
Mould number	E15-01-01
ERP	VC.0029




Engine	FD46
OEM	
Mould number	FD46-01-01
ERP	VC.0452




Engine	GA16DS
OEM	10101-74Y85
Mould number	GA16DS-01-01
ERP	VC.0173




Engine	HR16DE
OEM	13270-ED000
Mould number	HR16DE-01-01
ERP	VC.0168




Engine	KA24DE/U13
OEM	13270-1E401
Mould number	KA24DE-01-01
ERP	VC.0218




Engine	KA24E/D22
OEM	13207-70F01
Mould number	KA24E-01-01
ERP	VC.0222




Engine	LD20
OEM	13270-G5500
Mould number	LD20-01-01
ERP	VC.0172



Engine	MR20DE
OEM	
Mould number	MR20DE-01-01
ERP	VC.0059



Engine	NA20S
OEM	13270-40F00
Mould number	NA20-06-01
ERP	VC.0201



Engine	UD(PE6T)
OEM	13270-96001
Mould number	PE6T-01-02
ERP	VC.0367



Engine	QG18DE(N16)
OEM	13270-4M500
Mould number	QE18DE-01-01
ERP	VC.0176



Engine	QG16DE
OEM	13270-4M700
Mould number	QG16DE-01-01
ERP	VC.0203



Engine	QR25DE
OEM	
Mould number	QR25DE-01-01
ERP	VC.0109




Engine	RB25 DET(R34)




<tbl\_r cells="2" ix="3" maxcspan="1" maxrspan="1" usedcols




MITSUBISHI




Engine	4A91
OEM	MW251251
Mould number	4A91-01-01
ERP	VC.0304




Engine	4B11
OEM	
Mould number	4B11-01-01
ERP	VC.0305



Engine	4D30
OEM	ME011205
Mould number	4D30-01-01
ERP	VC.0194




Engine	4D34
OEM	ME011279
Mould number	4D34-01-01
ERP	VC.0216




Engine	4D35
OEM	
Mould number	4D35-01-01
ERP	VC.0211




Engine	4D55/4D56/4D56T
OEM	MD050312
Mould number	4D56-01-01A
ERP	VC.0192




Engine	4D56
OEM	
Mould number	4D56D-01-01
ERP	VC.0395




Engine	4D56T/L200
OEM	
Mould number	4D56T-01-01
ERP	VC.0387




Engine	4D65
OEM	MD012908
Mould number	4D65-01-01
ERP	VC.0159




Engine	4DR5
OEM	
Mould number	4DR5-01-01
ERP	VC.0191




Engine	4G13
OEM	MD030282
Mould number	4G13-01-01
ERP	VC.0105



Engine	4G15
OEM	MD143995
Mould number	4G15-01-01
ERP	VC.0098



Engine	4G15
OEM	MD312914
Mould number	4G15-02-01
ERP	VC.0396



Engine	4G15M
OEM	
Mould number	4G15M-01-01
ERP	VC.0306



Engine	4G32
OEM	MD07383
Mould number	4G32-01-01
ERP	VC.0149



Engine	4G41
OEM	
Mould number	4G41-01-01
ERP	VC.0335



Engine	4G63-8V
OEM	MD130494
Mould number	4G63-05-01
ERP	VC.0315



Engine	4G63
OEM	MD125939
Mould number	4G63B-01-01
ERP	VC.0160




Engine	4G63S4M
OEM	MD310913
Mould number	4G63C-01-01
ERP	VC.0151



Engine	4G69
</




MAZDA



Engine	B3
OEM	KY01-10-235
Mould number	B3-01-01
ERP	VC.0119




Engine	B3A
OEM	B630-10-235B
Mould number	B3A-01-01
ERP	VC.0457




Engine	BP05
OEM	
Mould number	BP-01-01
ERP	VC.0358




Engine	E3/E5
OEM	E301-10-235
Mould number	E3-03-01
ERP	VC.0025




Engine	E1600 NA MA
OEM	0221-10-235A
Mould number	E1600-01-01
ERP	VC.0187



Engine	E1800/F8
OEM	F801-10-235D
Mould number	E1800-01-01
ERP	VC.0353




Engine	E2000/FE8M
OEM	F8B5-10-235
Mould number	E2000-01-01
ERP	VC.0206




Engine	F2
OEM	F201-10-235D
Mould number	F2-01-01
ERP	VC.0137




Engine	FP
OEM	FS01-10-235A
Mould number	FS-01-01
ERP	VC.0307
AJUSA	11056400



Engine	FSD7
OEM	FSD7-10-235
Mould number	FSD7-01-01
ERP	VC.0129
AJUSA	56031100



Engine	JE26/JE27
OEM	K101-10-270A.R
Mould number	JE26-01-01
ERP	VC.0340
AJUSA	56018000



Engine	JE26/FE27
OEM	JE26-02-01
Mould number	JE26-02-01
ERP	VC.0341
AJUSA	56017900



Engine	LFD LF L3
OEM	LF14-10-230
Mould number	M6-01-01
ERP	VC.0193
AJUSA	



Engine	F3/E2200/R2T/RF
OEM	RFP1-10-235
Mould number	R2-01-01
ERP	VC.0301
AJUSA	



Engine	T3500/SL
OEM	SL01-10-235
Mould number	T3500-01-01
ERP	VC.0355
AJUSA	



Engine	UC
OEM	0324-10-235
Mould number	UC-01-01
ERP	VC.0351
AJUSA	



Engine	WE
OEM	WE01-10-235
Mould number	WE-01-01
ERP	VC.0346
AJUSA	



Engine	WL
OEM	WL01-10-235
Mould number	WL-01-01
ERP	VC.0348
AJUSA	



Engine	ZM/ZL
OEM	ZL01-10-235
Mould number	ZL-01-01
ERP	VC.0103
AJUSA	



Engine	TD42
OEM	
Mould number	TD42-01-01
ERP	VC.0241
AJUSA	


Engine	JE




<tbl\_r cells="2" ix="4" maxcspan="1" maxrspan="1




SUZUKI



Engine	F10A
OEM	11189-73000
Mould number	462-01-01
ERP	VC.0047



Engine	A94-0032C/K10A
OEM	
Mould number	A94-01-01
ERP	VC.0076




Engine	F6A
OEM	
Mould number	F6A-01-01
ERP	VC.0041




Engine	(F8A)
OEM	
Mould number	F8A-01-01
ERP	VC.0048



Engine	G10A
OEM	
Mould number	G10A-01-01
ERP	VC.0343




Engine	G13B
OEM	11189-71C00
Mould number	G13B-01-01
ERP	VC.0085




Engine	H20A
OEM	
Mould number	H20A-01-01
ERP	VC.0111



Engine	H20A
OEM	
Mould number	H20A-02-01
ERP	VC.0078



Engine	J20A
OEM	
Mould number	J20A-01-01
ERP	VC.0422



Engine	K6A
OEM	
Mould number	K6A-01-01
ERP	VC.0391



Engine	K6A
OEM	
Mould number	K6A-02-01
ERP	VC.0502



Engine	K14B
OEM	
Mould number	K14B-01-01
ERP	VC.0107



Engine	K14B 出口版
OEM	D1010819
Mould number	K14B-02-01
ERP	VC..0487




Engine	M16
OEM	11189-54G00
Mould number	M16-01-01
ERP	VC.0142




Engine	K12B
OEM	11189M83K00-000
Mould number	K12B-01-01
ERP	VC.0518




ISUZU




Engine	4BC2
OEM	8-94462-551-0
Mould number	4BC2-01-01
ERP	VC.0209




Engine	4BD1
OEM	5-11173-016-0
Mould number	4BD1-01-01
ERP	VC.0352




Engine	4HF1
OEM	
Mould number	4HF1-01-01A
ERP	VC.0035




Engine	4HF1
OEM	
Mould number	4HF1-01-01B
ERP	VC.0236




Engine	4HF1
OEM	8-97189871-1
Mould number	4HF1-01-01C
ERP	VC.0237




Engine	4HF1
OEM	
Mould number	4HF1-01-01D
ERP	VC.0269




Engine	4HK1
OEM	8-97331360-1
Mould number	4HK1-01-01
ERP	VC.0324




Engine	4HK1
OEM	
Mould number	4HK1-02-01
ERP	VC.0325



Engine	4JA1
OEM	8-94247-903-1
Mould number	4JA1-01-01
ERP	VC.0256



Engine	4JB1/600P
OEM	8-97161131-0
Mould number	4JB1-01-01
ERP	VC.0054




Engine	4JJ1
OEM	
Mould number	4JJ1-01-01
ERP	VC.0387



Engine	4KH1/600P
OEM	8-97349416-1
Mould number	4KH1-01-01
ERP	VC.0332



DAIHATSU



Engine 1KR-DE2

OEM

Mould number 1KRDE2-01-01

ERP

VC.0506




Engine KF-DE PF.DA.018B

OEM

Mould number KFDE-01-01

ERP

VC.0488




Engine ED

OEM

Mould number DLA-01-01

ERP

VC.0042



Engine EJ-DE

OEM

11213-97202-000

Mould number DLD-01-01

ERP

VC.0046



Engine DG


OEM

DG-01-01

Mould number DG-01-01

ERP

VC.0061



Engine K10A K12A 468 471

OEM

11189-75F01

Mould number S89-01-01

ERP

VC.0094



Engine DL

OEM

11253-87304-00

Mould number DL-03-01

ERP

VC.0175



Engine K3VE

OEM

11213-97401

Mould number K3VE-01-01

ERP

VC.0190



Engine DL

OEM

11213-87306

Mould number DL-01-01

ERP

VC.0202



Engine HE-EG/HD-EF

OEM

11213-87104

Mould number HE-EG-01-01

ERP

VC.0092



Engine F10/DG/JV

OEM

11213-87304

Mould number F10-01-01

ERP

VC.0339



Engine DG

OEM

DG

Mould number DG-02-01

ERP


VC.0194



HINO




Engine	EF750
OEM	
Mould number	EF750-01-01
ERP	VC.0230




Engine	EH700
OEM	
Mould number	EH700-01-01
ERP	VC.0239



Engine	EK100
OEM	
Mould number	EK100-01-01
ERP	VC.0198



Engine	HO6C
OEM	
Mould number	HO6C-01-01A
ERP	VC.0245




Engine	J05C
OEM	
Mould number	J05C-01-01
ERP	VC.0336



Engine	J05C
OEM	
Mould number	J05C-02-01
ERP	VC.0331




Engine	J05E
OEM	S1121-32020/11213-1920
Mould number	J05E-01-01
ERP	VC.0415




Engine	J08C
OEM	
Mould number	J08C-01-01
ERP	VC.0227




Engine	J08C
OEM	
Mould number	J08C-02-01
ERP	VC.0254




Engine	K13C
OEM	
Mould number	K13C-01-01
ERP	VC.0376



Engine	P11C
OEM	
Mould number	P11C-01-01
ERP	VC.0384



Engine	P11C
OEM	
Mould number	P11C-02-01
ERP	VC.0386



Engine	W04D
OEM	
Mould number	W04D-01-01
ERP	VC.0212