

YIWU GREAT SEAL RUBBER PRODUCTS COMPANY

gsealing.com

Whatsapp: 008613819535862

admin@gsealing.com

TOYOTA OIL SEAL LIST

OEM NO	APPLICATION AND NAME
90313-13001	wave box oil seal
90311-15001	Steering gear/steering rack seal
	Fuel injector seal
90099-15003	Fuel injection pump seal
90311-18001	Steering worm seal
90311-17062/90311-17092	Steering worm seal
90311-18002	Remove fork cover oil seal
90029-21005/90029-21006	oil pump
15165-70010/90311-70040	oil pump
90311-18001	Steering worm seal
90311-19002	Steering worm seal
90311-19012	steering rack seal
90311-19002	steering rack seal
90311-19001	steering worm /DAI worm
90311-19007	steering rack seal
90311-20006	
90029-21007/90029-21020 /90029-21021	oil pump
15165-64010	oil pump
90316-20006/90043-16008	Shock absorber
90029-21022	oil pump
90311-23004	Input shaft
	steering rack seal
90311-24001	steering rack seal
90311-25011/90311-25016	Change speed inside/before
90310-25004	steering rack seal
1-09625-133-0/909924-2090 /909924-5150/94034132 /90310-25006/90311-25002	Fuel injection pump seal
90311-25021	oil pump
11193-16010	spark plug seal
11193-15010-4AF	spark plug seal
11193-15010	spark plug seal
90310-28038/9-49150-007-0	Turn to the fan
90310-28014	Turn to the fan
90311-28003/90311-28004	transmission
90304-28014-71	
	spark plug seal
90311-28003/90311-28004	winch worm
23682-30020	spark plug seal
	spark plug seal

90311-30002/90311-30005 /MD152603/MD177097	front/inside / camshaft
90311-30001	
90311-30115	transmission
8-94334-845-0/8-94389-593-0 /8-94389-593-1/90311-30010	transmission
90312-32002	Steering gear
90312-32001	
90310-32024/90311-32024	Steering fan
90311-32001/90311-32017 /90311-32018/90311-32020 /90043-11284	VOLK/crankshaft/camshaft/
90311-32013/90311-32106 /MX000033/90043-11109	
90311-32010/90311-32011	TO/DAI transmission
90311-32012/8-97165-084-0	TO/DAI/HI/IS transmission
90311-50001/212-2401060	halfshaft
90311-32018	camshaft
90311-33085	half shaft
90311-34005/90311-34007	附件箱
90311-34016	drive axle seal
90311-34012	
90311-34022	half shaft
90311-34013	half shaft
90310-35001	rear wheel seal
	rear wheel seal
90311-35001/91250-SB0-625	
90311-35008/90311-35013 /90311-35017/90311-35022 /90311-35040/90311-35049	crankshaft/camshaft/
90311-35003	camshaft seal
43232-E4100/90310-35005 /90310-35010	drive shaft seal
90311-35019	half shaft
90311-35046	differential oil seal
90311-36002	Steering fan
	front crankshaft
90311-38025	camshaft seal
90311-38025/90311-38044	camshaft seal
90311-38017/90311-38018 /90311-38036/90311-38046 /90043-11229	camshaft seal
90311-38051	camshaft seal
90311-38034	camshaft seal
90311-38037	rear wheel seal
90311-38074	halfshaft
90311-38029	wave box oil seal
22881-82300/96053884 /90311-38020/94840652	transmission
90311-38020	transmission
90311-38043	transmission
90311-38140/90311-38032	transmission

90311-38076	半轴左
90311-38011/90311-38071	half shaft
90311-38007/90311-38093	rear crankshaft
90311-38014/90311-38015 /90311-38057/90311-38124	differential oil seal
90311-38047/90311-38035 /90311-38070	differential oil seal
90311-38010/90311-38028 /90311-38079/90311-38133	differential oil seal
MK039F2	front crankshaft
90311-38022	front crankshaft
90311-38002/90311-38024 /90311-38111	front crankshaft
90311-38013/90311-38138	front crankshaft
90310-40001	rear wheel seal
90311-40108/90043-11206	front wheel seal
	front wheel seal
90311-40006/90311-40013	曲前/油泵
90311-40004	differential oil seal
90311-40001	wave box oil seal
90311-40026/28	wave box oil seal
90043-11342	differential oil seal
90311-40020	camshaft
90311-40016	
	front wheel seal
90311-41123	front wheel seal
90311-41001/90311-41003	rear wheel seal
90311-41002/90311-41004 /94845317	rear wheel seal
90311-41008	halfshaft
	front crankshaft
90311-42006/90311-42018	rear crankshaft
0187-26-154/9S9V3-42008 /09283-42008/90311-42055	rear wheel seal
90311-42027/8067-42160	camshaft
90311-42024	wave box oil seal
90311-42003/90311-42008 /90311-42012/90311-42019 /90311-42026	crankshaft/camshaft seal
90311-42032/90311-42035	front crankshaft
90311-42001/90311-42007 /N3A1-10-507/31344-X6901	front crankshaft
0326.22	front crankshaft
9004A-31018	
90311-T0006	half shaft
90311-45003	front crankshaft
90311-45001/90311-45018 /F3016-04522	differential oil seal
90043-11317	drive axle seal
90311-T0005	half shaft
90311-45014	
90311-45008	front crankshaft

13042-32200/13510-E0700 /90311-45006/90311-45011	front crankshaft
13510-78200/90311-45002	front crankshaft
90311-46001	front crankshaft
90311-47012	half shaft
90311-48013	front wheel seal
90311-47010/90311-47013	half shaft
90311-47001/90311-47048	rear wheel seal
	front wheel seal
90311-48122	front wheel/rear wheel seal
90311-48001	front wheel/rear wheel seal
90311-48018	wave box oil seal
90311-48010A/90311-48016	output shaft
90311-48011	transmission
90311-48010	
90313-48001/90313-48002 /90313-48005	rear crankshaft
90311-48014	front crankshaft
0221-10-602/0221-10-602A /0221-10-602B/D27Z-6700A /31311-60100/31311-60101 /90311-48002/90311-48004	front crankshaft
90311-48009	output shaft
90311-48135/90311-48089	transmission
90311-50005/90311-50136	front wheel seal
90311-50017	front crankshaft
90311-50015	transmission
90311-50026/28	half shaft
90310-50001/90310-50039 /90311-50030	rear wheel seal
90311-50013	front crankshaft
90311-50002/90311-50006 /90311-50007/90311-50049	front crankshaft
90311-50003	front wheel seal
90311-50024	differential oil seal
90311-50010/1	half shaft
90311-52059/90043-11250 /MA181498/MA125991	DAI/MI(FUSO) rear wheel seal
90311-52006/94846345	front wheel outer seal
04422-20010-52/04422-10010-52/94840654-52/90311-52001/90311-52008	rear wheel seal
90311-52003/90311-52013	front wheel seal
90311-52022	front crankshaft
90311-52005	rear wheel seal
	rear wheel seal
90311-54003	front wheel seal
MH034027/34711-11700 /90043-11080/90043-11287	front wheel/rear wheel seal

90310-56044	rear wheel seal
90313-T0002	
90311-56006	
90311-56008	front wheel seal
90311-56016	front wheel seal
90311-56007	rear wheel seal
90311-56001	rear wheel seal
04422-20010-56	front wheel seal
90310-T0008	
90311-58006	front crankshaft
90311-58007/9828-58104A	front crankshaft
90311-58003	differential oil seal
90311-58010	differential oil seal
90311-58002	differential oil seal
90311-60017	transmission
90311-62004	Drive axle seal
90311-62004	halfshaft
90311-62001/90311-62147	rear wheel inner seal
90311-62002	rear wheel inner seal
90311-63001/90311-63002	rear wheel seal
90311-65003	rear crankshaft seal
9828-65109/9828-65107 /9828-65108/1828-6502-00 /1828-6508-00/1828-6509-00	differential oil seal
90311-66002	front wheel seal
90311-66001	front wheel seal
90311-68001	front wheel seal
90311-68101	
90311-68002	front wheel seal
90311-70003/90311-70004 /90311-70007/90311-70075 /90311-70105/90311-70120 /90311-70950-71 /90311-70951-71/94840023 /90043-	rear crankshaft seal
90311-70001/MM406242 /MH034153/90311-70003	rear crankshaft seal
90311-70011	front wheel seal
90043-11292/90311-73001	rear crankshaft seal
90311-75004/90311-75006	rear crankshaft seal
90311-75007	rear crankshaft seal
307-13-12771/90311-75113 /MH034068/MH034155	rear wheel seal
90311-75039/07012-00075 /07012-10075	rear wheel seal
90311-75016	rear crankshaft seal
90311-75003	rear wheel seal
90311-75020	rear crankshaft seal
90311-76001	rear crankshaft seal
90311-C0007	rear crankshaft seal
90311-76002	rear crankshaft seal

	front wheel seal
90311-78001	rear wheel seal
90043-11230/90311-80007 /90311-80003/90311-80004 /90311-80008/90311-80012 /90311-80950-	rear crankshaft
	rear crankshaft
90311-80010	rear crankshaft
12209-T7202	rear crankshaft
90311-80001/90311-80002 /90311-80068/90311-80139	rear crankshaft
90311-82001	rear wheel seal
90311-85004/90311-85007 /90311-85008/90311-85001 /90311-85003	rear crankshaft
90311-85006	rear crankshaft
90311-85001	rear crankshaft
90311-88003/90311-88005	rear crankshaft
90311-88001	rear crankshaft
	rear crankshaft
90311-89001	rear crankshaft
0127.28	rear crankshaft
90311-90004/90311-90002 /90311-90003/90311-90008	rear crankshaft
90311-90006	rear crankshaft
90311-90008	rear crankshaft
90311-92001	rear crankshaft
90311-92008	rear crankshaft
90311-92005	rear crankshaft seal
90313-93001	shaft oil seal
90311-95007/90311-95012	rear crankshaft seal
90311-95008	rear crankshaft seal
90311-95001/124411-01780	rear crankshaft seal
90311-95003	rear crankshaft seal
90311-99009	rear crankshaft seal
	rear crankshaft seal
90311-99065	rear crankshaft seal
90311-99065	rear crankshaft seal
90311-99002/9828-00109A /9828-00109	rear crankshaft seal
9828-01137/9828-01137A /9828-01147/2445-6623-00 /2445-6624-00/90031-19001	front wheel seal
90311-99005/90311-99005A	rear crankshaft seal
90310-99042	rear wheel inner seal
90311-99020	rear crankshaft seal